

Sports 250 Scooter Set up Instructions

1. Once removed from the crate set scooter on its' center stand.
 - a. Place one hand on the cargo rack support and one hand on the handle bar.
 - b. Place your foot on the center stand and press downward.



2. From under the seat remove all parts.
3. Attach the side view mirrors.
 - a. First press rubber bushings into place on the bottom of each mirror



- b. Plug in each wire; wires are color coded.



- c. Place the provided brass bushing between mirror and mirror mount.



- d. With 6mm allen head wrench tighten bolt and insert rubber plug.



4. With a Phillips head screw driver remove the 4 face mask screws and the face mask.



5. With a Phillips head screw driver remove the 5 windshield screws.



6. Hold the windshield in place and mount it with the 5 windshield screws you just removed.



7. Reinstall the face mask.



8. Install the rubber mat floor boards by aligning the dimples of the mat with the holes in the floor boards and press into place.



9. BATTERY

- a. Put on protective gloves
- b. Remove red strip covering acid ports from battery.
- c. Press acid container firmly into battery allowing acid to flow into battery.
- d. Let acid settle in battery for about 10 minutes.
- e. Place black cap into acid ports and press firmly to secure.
- f. Let battery charge on 15A for about 30 minutes.
- g. Place battery into electric box.
- h. Place rectangular nuts under each pole of the battery.



- i. Insert both red and green battery cable through battery cap by way of square cut out. Bolt the green cable to the – pole and the red cable to the + pole. Bolt battery cap into place.



10. Under your seat you will find a set of blank keys as well as the security control.



11. Always check your oil before riding.
 - a. Unscrew oil cap, wipe off and screw cap back in.
 - b. If oil does not cover to the shredded section of the dipstick add oil.
 - c. Recommended oil is 10W-40.



12. Locate the fuel cap just in front of the seat and fill the unit with fuel



13. In order to start the unit
- a. Turn the key into the ON position
 - b. Turn the RUN switch on
 - c. Hold at least one brake
 - d. Push start button

